

INFANT SINK BATHER

WARNING

- Check this product regularly before using it and discontinue the use of the product if it becomes damaged, broken, or disassembled. Do not substitute parts. Contact Contours if replacement parts or additional instructions are needed (1-888-226-4469).
- Always test the temperature of the water being used in the infant bather prior to placing baby into the product. The typical water temperature for bathing a baby should be between 90 and 100°F (32.2 and 37.8°C).

Child Use Range:

0 - 6 Months. Discontinue use of the bather when your child begins trying to sit up or reaches 20 lb (9 kg), whichever comes first.

DROWNING HAZARD: Babies have drowned while using infant bathtubs.

- **STAY** in arm's reach of your baby.
- Use **ONLY** in empty sink.
- Keep drain open in sink.
- **NEVER** use in Adult or Infant Tubs.
- **NEVER** rely on a toddler or preschooler to help your baby or alert you to trouble. Babies have drowned even with other children in or near bather.
- **NEVER** leave your baby unattended in the bather, even for a few moments. If you need to leave the room, take your baby with you.

FALL HAZARD: Babies have suffered head injuries falling from infant bathtubs.

- Place bather **ONLY** in sink.
- **NEVER** lift or carry baby in the product.
- **STOP** using product when baby starts trying to sit up or has reached 20 lb (9 kg), whichever comes first.
- **NEVER** use on elevated surfaces.
- Check the stability of the product before placing your baby in the product.

CARE & MAINTENANCE

- For best drying results, hang dry bather after each use.
- Machine wash bather cold/gentle, tumble dry. Do not iron. Only non-chlorine bleach when needed.
- Note: the zipper at the base of the bather is not meant for consumer assembly/disassembly. Please do not tamper. No disassembly is needed to wash the bather.

PRODUCT REGISTRATION FOR SAFETY ALERT OR RECALL ONLY

We will use the information to contact you only if there is a safety alert or recall for this product. We will not sell, rent or share your personal information. To register your product, please visit our online registration at www.kolcraft.com/register



Scan for instructional video




Love us . . . leave a review!



Escanee para obtener
instrucciones en español


PARTS LIST

Bather




OPTIMAL USE POSITION

Place bather in sink.




NOTE: When bathing your child, always keep at least one hand on your child.

OPTIMAL USE SINK SIZE



← 13.5"-14" →



The diagrams shown here illustrate the bather's optimal sink fit. Scan the QR code to learn more about using the Cozy™ in your home.